

SERIES 2010

ENVIRONMENTALLY SEALED TIME AND DATA COLLECTION TERMINAL



Accu-Time Systems, Inc.

420 Somers Road, Ellington, CT 06029

Tel: (860) 870-5000 Fax: (860) 872-1511

Web Site: www.accu-time.com



Copyright©1998 Accu-Time Systems, Inc. Second printing, 1998. Accu-Time is a registered trademark of Accu-Time Systems, Inc. The material contained in this manual is subject to change. No part of this manual may be reproduced or distributed in any form or by any means, or stored in any database or retrieval system, without Accu-Time's prior written permission. Accu-Time Systems, Inc. makes no warranty of any kind including, but not limited to, any implied warranties of merchantability, and fitness for a particular purpose in regard to this manual.

All Rights Reserved. Printed in the USA

ACCU-TIME® SERIES 2010

TABLE OF CONTENTS

| | |
|--------------------------------|----|
| Introduction | 1 |
| Features and Options | 2 |
| Specifications | 3 |
| Installation | 4 |
| ACCU-RATE™ Diagnostics | 11 |
| Ethernet Setup and Testing | 16 |
| Maintenance | 19 |
| Troubleshooting Guide | 20 |
| Ethernet Troubleshooting Guide | 22 |

INTRODUCTION

The Accu-Time® Series 2010 is a NEMA 4X rated environmentally protected, true “C” programmable Time and Data Collection Terminal. The durable enclosure insures protection in an indoor/outdoor time and data collection environment. The Series 2010 offers a large user memory base of up to 768K for file validation, local editing and scheduling functions. In addition to operating in standard EIA communication formats, the Series 2010 has an optional TCP/IP ETHERNET 10-base-T format. Among the many features of the Series 2010 are:

- ◆ **Multi-Media:** Can support most standard bar code formats including UPC, 128, 39, 2/5, I2/5 and more, as well as proximity technology.
- ◆ **Flexibility:** The Series 2010 can act as a stand alone time station or as part of a local or wide area network. The terminal can also interface with virtually any host hardware or software platform.
- ◆ **Custom Applications:** Custom programs and programmable function keys can provide users with the flexibility to create a variety of options.
- ◆ **Reliability:** A Real Time Clock (RTC) provides 12 or 24 hour time formats with quartz precision. An optional non-interruptible power supply (UPS) provides terminal operation for up to 4 hours during a power outage, for example. Data storage will be preserved for up to 4 days with the memory backup system.
- ◆ **Durability:** The NEMA 4X enclosure protects circuitry from environmental conditions such as splashing water, windblown dust, and rain. The housing remains undamaged by the formation of ice and, in addition, is corrosion-resistant. The NEMA 4X rating signifies a watertight and dust-tight seal. Optional terminal heater kits (PN: HTR/KO1) are available allowing the device to withstand temperatures ranging from –25° to 110° Fahrenheit. (Normal operating temperature range without heater option(s) is 32° to 110° F.)

Versatility, Reliability and Affordability in a state-of-the-art ergonomically designed terminal and backed by the ACCU-TEAM.

FEATURES and OPTIONS

- Single or multi-clock environments on a variety of host platforms with application programs integrating the ATS DATA TRAKER™ family of modules.
- Molded fiberglass polyester, NEMA type 4X, sealed environmental housing for indoor/outdoor use
- 128K Byte capacitor backed memory base, expandable to 768K
- TCP/IP ETHERNET 10-base-T compatible (802.3)
- EIA Standard RS232 or RS485 compatible. Up to 9600-Baud Modem operation
- On-board ACCU-RATE™ terminal set-up and diagnostics package.
- Custom keypad legends with software defined function keys
- Large 20 key tactile 4x5 matrix keypad
- 4 Line x 20 Character liquid crystal back lit display
- Dual tone audible annunciator
- Diagnostic LEDs for Ethernet circuitry. Detailed in troubleshooting guide.
- Externally mounted or integrated onto a mounting plate, weather resistant proximity or visible/infrared Bar Code readers
- DI/DO port for access control
- Optional Printer port
- Low voltage power source locally or remotely supplied
- Non-interruptible power source with on-board charger
- FCC part 15 Certified

SPECIFICATIONS

| | |
|----------------|--|
| Display: | 4 Line x 20 Character backlit super-twist LCD |
| Clock: | 12 or 24 hour-format-USA or International (quartz precision) Time stamp of data transactions |
| Indicators: | Yellow LED Low Power indicator Two programmable LED indicators, RED and GREEN Diagnostic LEDs for Ethernet: Yellow = busy Green = linked Yellow = receive Red = Transmit |
| Memory: | 128K Byte of capacitor backed memory (I.e.; 600-employee base-program dependent) Expandable to 768K Byte (Over 2000-employee base—program dependent). |
| Programming: | ATS DATA TRAKER™ modules, “C” programming language or third party custom application packages. |
| Interface: | TCP/IP ETHERNET 10-base-T (802.3) EIA Standard RS232 or RS485 (2 or 4 wire) Standard AT Command set. Internal 12/2400-baud Modem operation. DI/DO or Serial Interface Printer port. |
| Enclosure: | Molded fiberglass polyester, sealed environmental housing for indoor/outdoor use NEMA 4X approved |
| Power: | +10 to +17 VDC (+12 VDC @ 365 milliamps Nominal) Local, remote or centrally powered Non-interruptible power source with charger (optional) (Heater kit(s) may require additional power) |
| Environment: | Operation: 32° to 110° F (0° to 43° C) Terminal heater kits: -25° to 110° F |
| Certification: | FCC part 15 |
| Physical: | 8.5” wide x 6.25” high x 10.5” long. Weight: 8.6 LBS 21.6cm wide x 15.9cm high x 26.7cm long Weight: 3.9 kg |
| Accessories: | Integrated/External visible/infrared weather resistant Bar Code slot readers Integrated/External weather resistant proximity readers Solid State or Dry Contact relay modules Serial Interface Printer Port |

INSTALLATION

GENERAL INSTALLATION GUIDELINES

Environment

The Series 2010 Time and Data Collection Terminal is a durable industrial-grade device, which will endure harsh environments. The ATS[®] terminal is designed to operate indoors and outdoors. The NEMA 4X enclosure serves as a safeguard against splashing water, rain, windblown dust, and hose directed water. The Series 2010 may operate with an internal heater element (part number: HTR/KO1) allowing functionality up to 110° and down to -10° Fahrenheit. With a second heater option, the temperature range expands to -25° Fahrenheit.


The terminal should be mounted on a vibration free area. Select a location, which has adequate lighting and accessibility to operate the terminal safely.

Operating Parameters

The RS232 Series 2010 must be located no greater than fifty (50) wire-feet from the host computer. EIA standards for RS232 protocol data transmission dictate this cable distance. Exceeding this requirement greatly increases the chances for continual data re-transmission, which may never be acknowledged.

The RS485 Series 2010 locally powered must be located no greater than five thousand (5000) wire-feet from the host computer. EIA standards for RS485 protocol data transmission dictate this cable distance. Exceeding this requirement greatly increases the chances for continual data re-transmission, which may never be acknowledged.

The ETHERNET Series 2010 may be located at any point within a TCP/IP ETHERNET 10-base-T Network, providing the single segment length from the network hub does not exceed three hundred and twenty-eight (328) wire-feet. A typical topology for the Series 2010 in an ETHERNET 10-base-T network is a star configuration.




INSTALLATION

Since the Series 2010 is an environmentally sealed device, all cables supporting the peripheral devices, communications and power sources must be inserted through the appropriate watertight connectors. Observance to this requirement will ensure watertight integrity and protection against external elements.

- ♦ **Mounting**-The case and hinged front cover are made from a durable fiberglass polyester. (**NOTE:** *Use extreme caution when opening the enclosure to ensure that the keypad assembly does not abruptly detach from the terminal PC board, possibly causing connector damage.*) The sealed terminal comes with four plastic mounting ears. These ears should be secured to the bottom underside of the enclosure and extend out from the sides to allow for wall mounting. A special mounting plate is available if an integrated reader is purchased.
- ♦ **Cabling**- A twisted pair or category 5 style **round** cable is required. Select the appropriate seal tight connectors and remove the nylon plugs to accommodate data transmission and 12VDC power pack cable assemblies. The cable is passed through the seal tight connector that is then tightened down over the cable. One seal tight connector per cable is allotted (see diagram below). The supplied rubber tubing should be slid over the cable if the seal tight connector does not clamp the cable securely. This should be done before tightening the connector.
- ♦ **Power**- When terminal power is being supplied locally, insure that a conventional 110VAC-wall outlet 220VAC, in Europe and other areas, (check local electrical code requirements) is available to accept the Series 2010 power pack assembly. The outlet should be no further than four (4) feet from the terminal.
- ♦ **Base**- Locate a flat wall surface to accommodate the Series 2010. Typical mounting height is forty-eight inches from floor to the terminal display (Compliant to the Americans with Disabilities Act). Observe OSHA and/or local safety codes when operating tools during all phases of installation. Attach the four terminal mounting ears (or mounting plate) to a flat wall surface.

For RS232 communication applications, one end of the communication cable terminates into the Series 2010 communication port while the other terminates into the host computer's serial port via an ATS® RS232 Communication Adapter. For remote powering, a Network Junction Box or Network Junction Box Jr. could be used.

RS232 INSTALLATION




For RS485 communication applications, ATS® recommends using a data transmission cable that adheres to the following specifications:

- Five conductor shielded 24-gage wire with a drain.**
- The impedance of the cable should be 100 Ohms.**
- The capacitance should be 12 pico-farads per foot.**
- The jacket of the cable is typically a PVC material.**



(*NOTE* If the host is not equipped with an RS485 port, an ATS® RS232/485 Converter with 12 volt power pack assembly will convert the terminal communication lines to RS232 levels. The host output of the RS232/485 Converter plugs directly into the ATS® RS232 Communication Adapter).

RS485 allows for the Series 2010 to be used in multi-dropped networks. Thirty-two (32) terminals can be supported on a single host communication port. The use of ATS® Series 1000 Network Controllers allow up to five hundred and twelve (512) terminals on a single host communication port.

MULTI-CLOCK - RS485 INSTALLATION



For ETHERNET communication applications, ATS® recommends using a CATEGORY 5 unshielded twisted pair high-speed data transmission cable, which conforms to EIA/TIA standard 568B. One end of the **round** communication cable is screwed down onto the interface board, while the other end terminates into the network hub.



Terminal Cabling

Use extreme caution when opening the enclosure to ensure that the keypad assembly does not abruptly detach from the terminal PC board, possibly causing connector damage.


Select and remove the seal tight connector(s) and corresponding nylon plug(s) located on the outside of the housing. The screws, located at the bottom corners of the enclosure, should be loosened in order to slide the inner chassis forward and out. Pass the data cable through the appropriate seal tight connector and secure to the interface board in the base of the Series 2010 terminal (Figure 2). Tighten the connector down over the cable. Attach the output of the 12VDC power pack assembly (if power is not combined within the communication cable) into the power jack (PJ1) in the base of the Series 2010. The supplied rubber tubing should be installed if the seal tight connectors do not properly secure either cable. Place the jumper, located at JP1 on the I/O board, to the NC position (Figure 2). Plug the primary of the power pack assembly to the conventional wall outlet.

(*NOTE* If the host is not equipped with an RS485 port, an ATS® RS232/485 Converter with 12 volt power pack assembly will convert the terminal communication lines to RS232 levels. The host output of the RS232/485 Converter plugs directly into the ATS® RS232 Communication Adapter).

For Ethernet installations, the terminal power pack should be plugged into the back of the terminal.

Place the terminal's USE/TEST switch in the USE mode. (**NOTE:** Use extreme caution when opening the enclosure to ensure that the keypad assembly does not abruptly detach from the terminal PC board, possibly causing connector damage.)


The Series 2010 will power-up and display the on-line default message. (Refer to the *ATS SETUP MODE* section of this manual for terminal communication setup parameters) Attach the remaining end of the data cable into the host computer port. The Series 2010 is now ready for operation.



RS232 or 485 Communication Cabling

Figure 1


Underside of Chassis



*26 Position ribbon cable connects the processor board, located on the topside of the chassis, to the I/O board shown above.

Figure 2

RS232/485 communication board



Located in base of terminal enclosure.

- Screw down RS232 or RS485 communication cable to terminal block.
- If power is not supplied through communication cable, plug power into PJ1. Ensure that the jumper (JP1) is placed in the NC position.
- If power is supplied through communication means, the jumper (JP1) should be placed to the NC position.
- One end of the 1 foot RJ45 flat gray cable terminates into J1 while the other plugs into the Host port pictured above in Figure 1.

Ethernet Communication Cabling

Figure 1

Underside of Chassis





Figure 2



Located in base of terminal enclosure.

- Screw down the Ethernet communication (EIA/TIA 568B) cable to terminal block.
- The power pack assembly must plug into the power interface on the I/O board (located on the underside of the chassis assembly).
- One end of the 1 foot RJ45 flat gray cable terminates into J1 while the other plugs into the communication interface pictured above in Figure 1.

ACCU-RATE™ SET-UP AND DIAGNOSTICS

POWER UP

To power up the Series 2010 a 12 VDC source must be applied to the terminal power jack. The Series 2010, with the power ON/OFF switch placed in the ON position and the TEST/USE switch placed in the USE mode, beeps, executes a power up sequence, and displays the message “**TERMINAL LOCKED**”.

ACCESSING TEST MODE

To access the test mode:

- 1) **Slowly** lift the hinged cover to insure that the keypad connector does not abruptly bend or detach from the terminal PC board. Unplug the keypad connector from the board to fully access the terminal.
- 2) The PC board/metal cover assembly must be removed and turned over in order to locate the TEST/USE switch (closest to the fuse). This may be accomplished by loosening the four screws located at the bottom of the enclosure. Slide the switch into the TEST position (away from modular jacks). The Series 2010 displays “**ATS TEST MODE**”.
- 3) Replace and secure the board/metal cover assembly inside the enclosure, along with reattaching the keypad assembly.
- 4) By pressing the CLEAR key, the user can step through the selections. (*NOTE* Test mode may be exited at any time by placing the TEST/USE switch back to the USE position and pressing the CLEAR key).

SELECTIONS:

- **ATS TEST MODE:** Tests the Keypad, Display, Memory, Real Time Clock, and the Proximity or Visible/Infrared Bar Code reader.
- **ATS SET-UP MODE:** Configures the communication parameters—Baud Rate, Parity Bit, Terminal Address, and Terminal Application Type.
- **ATS NETWORK TEST:** Performs a terminal to host communication loop-back test. Verifies integrity of cabling.
- **ATS BATTERY TEST:** Checks the terminal battery backup option.
- **ATS DI-DO TEST:** Checks the Digital Input/Digital Output auxiliary port by performing a loop-back test.
- **ATS RESTART MODE:** Resets the terminal, clears all data from memory and performs a power-up sequence.

ATS TEST MODE

ATS TEST MODE checks the functionality of the terminal Keypad, Memory, Real Time Clock, and the Proximity or visible/infrared Bar Code reader.

The message “**ATS TEST MODE**” appears on the top line of the display. The 2nd line of the display indicates the program (EPROM) number(s). To enter the TEST MODE, press the ENTER key. The following information appears:

ATS TEST MODE (XXX) (YY)

The terminal displays **ATS TEST MODE** on the top line followed by two sets of numbers. The first number (XXX) indicates the amount of memory installed (in Kilobytes). The right most number (YY) indicates the terminal Real Time Clock incrementing in seconds (00-59).

Testing the Keypad

At this time the user may test the keypad assembly. The terminal PC board, keypad assembly, and hinged cover must be reattached to the enclosure for this test to be performed. Each time a key is pressed the terminal will beep and the key value will appear on the 2nd line of the display. Press the ENTER key. The message “**KEY INPUT ACCEPTED**” is displayed. Each time the ENTER key is pressed an internal test of the terminal communication port is performed. If an error is detected the message “**COMM PORT FAIL**” will display, the invalid light will flash and the negative acknowledgement beeper tone will cycle. This message will continue until power is removed from the terminal. Refer to the Troubleshooting Guide of this manual.

Testing the Badge Reader

ATS[®] TEST MODE accepts input from optical slot or proximity readers. To test the bar code reader, simply swipe the applicable bar coded badge. The terminal beeps and displays the badge data. To test the proximity reader, hold the badge 1-3 inches in front of the reading area until the terminal beeps and displays the badge data. The type of proximity badge must be compatible with the proximity reader type to ensure terminal acknowledgement.

To proceed to the ATS SETUP MODE press the CLEAR key.

ATS SETUP MODE

ATS SETUP MODE allows the operator to configure the terminal for communications with the host computer. The Series 2010 default parameters are set as follows:

| | |
|---------------------------|------|
| Baud Rate | 9600 |
| Parity | ODD |
| Address | 01 |
| Terminal Application Type | A |

To enter the ATS SETUP MODE, press the ENTER key at the “**ATS SETUP MODE**” display prompt. (Prior to pressing the ENTER key, the 2nd line of the display will indicate the current terminal setup values.)

Baud Rate

To change the terminal baud rate:

1. Press CLEAR to step through the baud rate choices:

19200
9600
4800
2400
1200
M1200 (modem)
M2400 (modem)
2. When the desired baud rate is displayed, press the ENTER key to store the value and advance to the next parameter.
3. If a modem baud rate is selected, a self-test will be performed on the modem. The results of this test will be displayed. The operator will be prompted to enter the number of auto answer rings.

NOTE: If no modem is installed and a modem baud rate has been selected, the modem self test will fail.

Parity

To change the parity:

1. Press the CLEAR key to step through the parity choices:

ODD
EVEN
NONE
2. When the desired parity is displayed, press the ENTER key to store the value and advance to the next parameter.

Address

To change the terminal address:

1. Press the CLEAR key to increment the address values from 01 to 32.
2. When the desired address is displayed, press the ENTER key to store the value and advance to the next parameter.

Terminal Application Type

The Terminal Application Type is used as a delimiter by the host for routing application information to the terminal. (Example-an access control terminal could have a different terminal type than a time and attendance terminal.) This value is typically left at A.

To change the terminal application type:

1. Press the CLEAR key to increment the type from A to J.
2. When the desired type is displayed, press the ENTER key to store the value and advance to the ATS NETWORK TEST.

ATS NETWORK TEST

ATS NETWORK TEST is a two-part test. The first allows the network wiring between the terminal and the host to be checked for open connections or wiring errors. This test requires that the ATS RS232 Communication Adapter which is plugged into the host, be unplugged and pins 2 & 3 of the adapter jumped together (a paper clip should do the trick). For RS485 installations, an ATS[®] 232/485 Converter is required. Secondly, a local test can be performed on the terminal communication circuitry. This test will work for both RS232 and RS485 installations. To enter NETWORK TEST, press the ENTER key at the “**ATS NETWORK TEST**” prompt. The following message appears:

**SWITCH TEST SWITCH
TO USE POSITON**

The enclosure must be opened **slowly** and disassembled to place the switch back to the USE position. The keypad should be reattached and the hinged cover closed after the switch is moved. The Series 2010 performs a network test in which the terminal sends data up to the host, via the network cabling. Since a temporary jumper was installed in the ATS RS232 Communication Adapter, the data will be looped back to the terminal. The following message should appear:

**NETWORK TEST PASS
ENTER TO RETEST**

To perform the local communication loop back, **slowly** disassemble the enclosure/terminal and place the USE/TEST switch back to the TEST position and press the ENTER key. The following message should appear:

**NETWORK TEST PASS
ENTER TO RETEST**

Remove the jumper from the RS232 Communication Adapter and secure it back into the host port. Press the CLEAR key to advance to the next test.

ATS BATTERY TEST

The ATS BATTERY TEST checks the terminal battery backup option if installed. To enter this test, press the ENTER key at the “**ATS BATTERY TEST**” prompt. The following message should appear:

**BATTERY TEST PASS
ENTER TO RETEST**

Note: If the battery backup option is not installed, the battery test will fail.

Press CLEAR to advance to the ATS DI-DO Test.

ATS DI-DO TEST

The ATS DI-DO Test is a two-part test that checks the terminal auxiliary DATA IN/DATA OUT port connection by performing a loop back communication test on the port circuitry. To enter the ATS DI-DO Test:

1. Press the ENTER key at the “**ATS DI-DO TEST**” prompt. The following message should appear:

**SWITCH TEST SWITCH
TO USE POSITION**

2. The enclosure must be opened **slowly** and disassembled to place the switch back to the USE position. Since no loop back jumper is installed during this phase of testing the following message will appear:

**DI-DO TESTING
DI-DO TEST FAILED
ENTER TO RETEST**

3. Place the TEST/USE switch into the TEST position. This will provide the terminal with its own loop back jumper. Reassemble the enclosure and keypad assembly.
4. Press the ENTER key. The following message should appear:

**DI-DO TEST PASSED
ENTER TO RETEST**

5. Press the CLEAR key to advance to ATS RESTART MODE.

ATS RESTART MODE

The ATS RESTART MODE *clears all* transaction data and any download from memory. To restart the terminal:

1. Press the ENTER key to select the ATS RESTART MODE. The terminal displays:

**PRESS ENTER TO CLEAR
ALL TRANSACTION DATA**

2. Press the ENTER key. The terminal displays:

CLEAR FOR CYCLE TEST
(Note: Cycle test is for factory diagnostics only)
ENTER FOR RESTART

3. Press the ENTER key. The terminal displays:

CLEARING MEMORY. . .

The green Valid LED will blink and the terminal will execute a power up sequence and return the terminal to the beginning of the Test Mode.

4. To exit the Test Mode, place the TEST/USE switch to the USE position, in the same fashion as stated earlier, and press the CLEAR key. The terminal will execute a power up sequence. The terminal displays: **“TERMINAL LOCKED”** The terminal can now accept a host download. Insure that the terminal is reassembled and the internal components are secure.

This completes the ACCU-RATE™ test and set-up

ACCU-RATE™ ETHERNET SET-UP AND DIAGNOSTICS

ATS TEST MODE checks the ETHERNET circuitry installed in the Time and Data Collection Terminals. To accurately test this circuit the following sequential steps should be adhered to.

NOTE: The Ethernet communication cable must be connected to the Time and Data Collection Terminal while running the Host software for this operation to be successful.

With the “TEST MODE” message in the terminal display, press the CLEAR key five (5) times. The message “ATS RESTART MODE” appears on the top line of the display. Press the ENTER key three (3) times to clear all memory prior to testing the ETHERNET circuit. **(Omitting this step greatly increases the chances of unreliable test results in the ETHERNET circuit).** After resetting, the terminal will again display “TEST MODE”.

Press the CLEAR key one (1) time. The message “ATS SETUP MODE”
Followed by: **TERM 000.000.000.000** displayed for one (1) second
Followed by: **HOST 000.000.000.000** displayed for one (1) second
Followed by: **GATE 000.000.000.000** displayed for one (1) second
(This message only appears if the gate address was previously loaded.)
Followed by: **MASK 000.000.000.000** displayed for one (1) second
Followed by: **BROADCAST ENABLED or DISABLED** displayed for one (1) second
Followed by: **APP ACK ENABLED or DISABLED** displayed for one (1) second
Followed by: **WATCHDOG ENABLED or DISABLED** displayed for one (1) second

The above sequence will repeat itself until either the CLEAR or ENTER key is pressed. Pressing the CLEAR key will bypass the test. Pressing the ENTER key will enable the test.

Press the ENTER key. The following message will be displayed:

TERMINAL IP ADDRESS ###. ###. ###. ###. _ _ _

This is the Time and Data Collection unit’s unique **Internet Protocol** address. (See your network administrator for assignment.)

Enter, via the terminal keypad assembly, the numeric IP Terminal address in blocks of three followed by the ENTER key. Once all four octets are entered the following message will be displayed:

HOST IP ADDRESS ###. ###. ###. ###. _ _ _

This is the Host’s unique **Internet Protocol** address. (See your network administrator for assignment.)
Enter the numeric IP Host address in blocks of three followed by the ENTER key. Once all four blocks are entered the following message will be displayed:

NETWORK MASK ###. ###. ###. ###. _ _ _

This is the Subnet Mask used for channeling. (See your network administrator for assignment).

Enter the numeric Mask address in blocks of three followed by the ENTER key. Once all four blocks are entered the following message will be displayed:

HIT ENTER IF DEFAULT ROUTE REQUIRED

If a Router or Gateway is required press the ENTER key. The following message will be displayed:

ROUTER IP ADDRESS ###. ###. ###. ###. _ _ _

This is the system Router used for directing Internet traffic among a variety of Hosts. (See your network administrator for assignment.) Enter the numeric Router or Gateway address in blocks of three followed by the ENTER key.

The next message allows an enablement of the Broadcast Receive command. If this function is disabled, all broadcast packets will be ignored by the terminal.

HIT ENTER TO ENABLE BROADCAST RECEIVE

Disabling Broadcast Receive may be accomplished by pressing the CLEAR key (recommended for networks with heavy traffic). Upon disablement, only devices connected to the same IP address will be able to “Ping” terminals.

The Application Acknowledgement message assures that the Host has received the last transaction, which enhances data integrity by affirming that the transaction has not been held up in a router/gateway or lost. The terminal will display the following:

HIT ENTER TO ENABLE APPLICATION ACK

Application Acknowledgement may be disabled by pressing the CLEAR key.

The next message, TCP/IP Watchdog, provides a “soft restart” if the connected terminal has not communicated with the Host for approximately ten- (10) minutes. The terminal will display the following message:

HIT ENTER TO ENABLE TCP/IP WATCHDOG

Pressing the CLEAR key will disable TCP/IP Watchdog.

The following message allows the Ethernet communication connection.

ENETADD=XXXXXXXXXXXXHIT ENTER TO CONNECT

The XXXXXXXXXXXXXX represents the unique Ethernet address programmed into the EPROM by ATS.

If a Router is not required Press the CLEAR key. The following message will be displayed:

ENETADD=XXXXXXXXXXXXHIT ENTER TO CONNECT

The XXXXXXXXXXXXXX represents the unique Ethernet address programmed into the EPROM by ATS.

Press the ENTER key or the CLEAR key if connection test is not required. The terminal will briefly display an initializing message followed by:

CONNECTING TO SERVER

If the connection to the server was successful the following message is displayed:

CONNECTION COMPLETE

If the connection to the server was **not** successful the following message is displayed:

CONNECTION FAILED!! HIT ENTER TO CONNECT

Press the ENTER key. The terminal will display the following:

CLOSING CONNECTION BEFORE RECONNECTION

Followed by the brief initializing message and connecting message:

CONNECTING TO SERVER

At this time the terminal will either complete the connection or fail.

If a connection failure occurs after numerous attempts, see the troubleshooting section of this manual for further assistance.

This completes the ACCU-RATE™ ETHERNET test

Downloading the Series 2010

The Series 2010 terminal, when used with the standard Time and Attendance "C" application, can be downloaded with employee names, badge numbers, schedules, etc. These download commands and others are explained in the ATS DATA TRAKER™ command set manual. For further information refer to this manual.

MAINTENANCE

The Series 2010 is a maintenance-free data collection device. The only required procedure is periodic cleaning of the optical bar code badge reader.

To clean the badge reader, swipe a pre-moistened (isopropyl alcohol) cleaning card through the reader several times. Low usage readers should be cleaned monthly. High usage readers should be cleaned weekly.

TROUBLESHOOTING GUIDE

Problem: Terminal does not power up and none of the status LEDs are lit.

Possible cause: No DC power applied

Solution: Ensure primary side of DC power pack assembly is plugged into a live AC outlet. Ensure secondary side of DC power pack assembly is plugged into the Time and Data Collection Terminal (DCT).

Solution: Check the fuse on the I/O board.

Problem: Terminal display is blank (no character or backlight).

Possible cause: The primary of the power pack assembly is not plugged into an AC-wall outlet.

Solution: Test the outlet by plugging in another appliance or check that the secondary supply is plugged into the terminal.

Solution: If all else fails, replace the power pack assembly.

NOTE: If the battery backup option is installed, the terminal will operate for approximately 4-hours when the primary voltage source is lost. After this, the terminal will power off. The yellow indicator light, located on the front of the terminal, will illuminate prior to the terminal blanking out.

Problem: Yellow Low Power indicator is lit.

Possible cause: Low DC power is attached.

Solution: Replace 12-volt DC power pack.

Possible cause: Terminal does not go blank after unplugging the battery connector.

Solution: Unplug and replace the power pack assembly.

Problem: Terminal is not communicating with Host.

Possible cause: The terminal TEST/USE switch is in the TEST position

Solution: Place the TEST/USE switch is in the USE position.

Possible cause: DCT to Host communication cable is defective or unplugged on either end.

Solution: Verify cable is tested and plugged into both ends.
(Ensure cable termination guidelines and lengths are observed.)

Solution: Ensure the application package is loaded and running on the host.

Possible cause: Communication parameters for the DCT do not match those of the Host.

Solution: Refer to the ACCU-RATE™ test and diagnostics section for set-up directions.

Problem: DCT does not accept badge data.

Possible cause: Bar code badge is not manufactured to proper specification.

Solution: Refer to vendor's specifications for manufacturing criteria.

Possible cause: Badge is being swiped in the wrong direction.

Solution: Ensure media faces to the right (away from the keypad).

Possible cause: Badge reader needs cleaning.

Solution: Swipe a pre-moistened (isopropyl alcohol) cleaning card through the reader several times.

Possible cause: Badge number does not exist in validation file.

Solution: See Supervisor

Note: If all solutions fail try reading badge in the ACCU-RATE™ test mode.

Problem: Terminal does not accept keypad input.

Possible cause: Keyed data does not exist in validation file

Solution: See Supervisor

Possible cause: Keypad connector is unplugged.

Solution: Test keypad in the ACCU-RATE™ test mode.

If all solutions have been explored and the problem still exists, contact the Accu-Time® Product Service Department at (860) 870-5000 during normal working hours 9 AM to 5 PM- Monday through Friday. Prior to contacting Accu-Time®, please have available the serial number and if possible the configuration number of the product.

NOTE: The DCT has no user serviceable parts. The Accu-Time® terminal must be operated within the parameters included in this manual. Any operation performed contrary to these parameters will void the warranty

POWER RELATED

Problem: The terminal display is blank (no characters or backlight).

Possible cause: The primary of the power pack assembly is not plugged into an AC-wall outlet.

Solution: Check the outlet, both ends of the power pack, and if it is a 12VDC power pack.

Solution: If all else fails, replace the power pack.

NOTE: If the battery backup option is installed, the terminal will operate for approximately 4-hours when the primary voltage source is lost. After this, the terminal will power off. The yellow indicator light, located on the front of the terminal, will illuminate prior to the terminal blanking out.

Problem: The low power (yellow) indicator LED is activated.

Possible cause: Outlet or power pack problem.

Solution: Perform the above solution if the terminal display goes blank upon removal of the battery connector.

COMMUNICATION RELATED

Problem: The terminal is not communicating with the host.

Possible cause: Communication parameters were not previously set.

Solution: Place terminal in Test Mode and step through ACCU-RATE™ Test procedures. The network administrator would provide the following:

- IP address to be assigned to the terminal
- IP address of the host to which the terminal can connect
- Network Mask (example 255.255.255.0)
- Gateway or Router address (if required)

Solution: If parameters are set, place terminal in Use Mode and perform a "ping" on the terminal.

Solution: Verify activity of LEDs located on the bottom of the terminal.

Solution: Verify that the cable is plugged into both ends (terminal and hub).

Solution: Verify that the single segment cable length is equal or less than the specified 328 feet. The cable should also be a 10-base-T category 4 or 5 twisted pair high-speed data transmission cable with both ends properly crimped.

Solution: Insure application package is loaded and running on the host.

Yellow: terminal is BUSY processing

Green: terminal is LINKED to host

Yellow: terminal data is being RECEIVED

Red: terminal data is being TRANSMITTED

Problem: A previously working terminal now is not operational.

Possible cause: TEST/USE switch is not in the Use position.

Solution: Place TEST/USE switch in Use position.

Possible cause: Cables not plugged in or host application software not operational.

Solution: Insure that all connections are made and that the host software application is functional. If possible, take a known working terminal, re-address it for this particular node and determine if the problem is related to the terminal, installation or host.

PERIPHERAL FAILURE

Problem: Bar code reader does not work.

Possible cause: The employee badge has not been added to the application database.

Solution: Place the TEST/USE switch into the Test position and swipe test badges to verify reader functionality.

Solution: If the reader works in the Test Mode and not in the Use Mode, verify that the employee badge has been added to the application database.

Problem: Keypad does not work.

Possible cause: Keypad function has been disabled in the application.

Solution: Place the TEST/USE switch to the Test Mode and press random keys to verify keypad functionality.

Solution: Insure that the keypad function within the application is activated.

If neither the standard nor Ethernet troubleshooting guide is of any help, please contact the Accu-Time Product Service Center, (860) 870-5000, for further assistance.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- * Reorient or relocate the receiving antenna.
- * Increase the distance between the time clock and the receiver.
- * Connect the equipment into an outlet on a circuit different from that which the receiver is connected.

FCC Warning: To assure continued FCC emission limit compliance, the user must use only the recommended shielded interfacing cable when connecting to a host computer. Also, any unauthorized changes or modifications to this equipment would void the user authority to operate this device.